



QUICK START GUIDE

BARRICADE XL

POWER-ON/OFF:



POWER ON:
 Press and hold the power button for 5 seconds until the LED indicator flashes red and blue. The device will power on and enter pairing mode.

POWER OFF:
 Press and hold the power button for 5 seconds until the LED indicator flashes red and blue. The device will power off.

PAIR NEW DEVICE:



PAIR NEW DEVICE:
 Press and hold the power button for 5 seconds until the LED indicator flashes red and blue. The device will enter pairing mode and be discoverable to other devices.

PAIRING MODE:



PAIRING MODE:
 The LED indicator flashes red and blue, indicating the device is in pairing mode. The device will be discoverable to other devices.

VOLUME UP:



VOLUME UP:
 Press the volume up button to increase the volume.

VOLUME DOWN:



VOLUME DOWN:
 Press the volume down button to decrease the volume.

PLAY/PAUSE:



PLAY/PAUSE:
 Press the play/pause button to start or pause playback.

TRACK FORWARD:



TRACK FORWARD:
 Press the track forward button to skip to the next track.

TRACK BACK:



TRACK BACK:
 Press the track back button to skip to the previous track.

REPEAT/SHUFFLE:



REPEAT/SHUFFLE:
 Press the repeat/shuffle button to toggle between repeat and shuffle playback.

MULTI-SPEAKER CONNECT:



MULTI-SPEAKER CONNECT:
 Press the multi-speaker connect button to connect two headphones for stereo sound.

MULTI-SPEAKER PAIRING:



MULTI-SPEAKER PAIRING:
 Press and hold the multi-speaker connect button for 5 seconds to enter multi-speaker pairing mode.

MULTI-SPEAKER PAIRING:



MULTI-SPEAKER PAIRING:
 Press and hold the multi-speaker connect button for 5 seconds to enter multi-speaker pairing mode.

MULTI USER PAIRING:



MULTI USER PAIRING:
 Press and hold the multi-speaker connect button for 5 seconds to enter multi-user pairing mode.

MULTI USER PAIRING:



MULTI USER PAIRING:
 Press and hold the multi-speaker connect button for 5 seconds to enter multi-user pairing mode.

CHARGE:



CHARGE:
 Connect the device to a USB-C cable to charge. The LED indicator will flash red when charging.

EXTERNAL CHARGING:



EXTERNAL CHARGING:
 Connect the device to a USB-C cable to charge. The LED indicator will flash red when charging.

EXTERNAL CHARGING:



EXTERNAL CHARGING:
 Connect the device to a USB-C cable to charge. The LED indicator will flash red when charging.

EXTERNAL CHARGING:



EXTERNAL CHARGING:
 Connect the device to a USB-C cable to charge. The LED indicator will flash red when charging.